

müller

140mm SPEEDOMETER & TACHOMETER Programming procedure and Mileage adjustment

Setup menu for programming

While holding the button, turn the ignition on. Hold the button until the LCD shows

0000
Pd

Enter the passcode **1213**

How to enter the passcode:

1. On the 1st digit from the right, push the button 3 times to change the value to **3**. Now **hold down the button for about 3 seconds to advance** to the next digit.
2. On the 2nd digit from the right push the button once to insert a **1** and then hold down again for 3 seconds to advance to the next digit.
3. On the 3rd digit from the right push the button twice to insert a **2** and then hold down again for 3 seconds to advance to the next digit.
4. On the 4th digit from the right push the button once to insert a **1** and then hold down again for 3 seconds to advance to the next menu.



After entering the passcode, hold the button again to advance to the **Settings Menu**

Following the same procedure as above to adjust the values.

The following can be adjusted:

Menu Codes	Description	Current Value
0 05096	Speed ratio (Calibration value)	5096
1 00110	Speed limit alarm value (km/h)	110
2 00005	Speeding alarm duration (seconds)	5
4 00200	R.p.m. ratio (Calibration value)	200
5 02200	R.p.m. limit alarm value	2200
6 00005	R.p.m. alarm duration	5

After adjustment, switch the ignition off and then on again.

Adjusting the Odometer

1. While holding the button, turn the ignition on. The LCD will show **0000**
2. Enter the new passcode **1214**
3. Follow the same procedure as above to adjust the values
4. After adjustment switch the ignition off and then on again

ALSO SEE  **YouTube** - **Muller Speedometer**